


HOSTAFORM® S 9364UV

True stress-strain



HOSTAFORM[®] S 9364UV

Processing Texts

Pre-drying

Drying is not normally required. If material has come in contact with moisture through improper storage or handling or through regrind use, drying to prevent splay and odor problems.

