

Technical information

TEREZ[®] PA 6 7500 GF 50

Medium viscosity Polyamide 6, 50% glass fibre reinforced.



TECHNICAL DATA SHEET

Product text

For Moulding parts of very high stiffness combined with good impact strength.

Properties	Value	Unit	Test method
Density	1,5600	g/cm ³	ISO 1183
Impact strength Charpy (Notched 23°C), dry	16	kJ/m ²	ISO 179
Impact strength Charpy 23°C, dry	90	kJ/m ²	ISO 179
Tensile-modulus, dry	16000	MPa	ISO 527
Tensile stress at break, dry	215	MPa	ISO 527
GWIT bei 3,0 mm	675	°C	IEC 60695-2-13
Elongation at break, dry	3,00	%	ISO 527
HDT 0,45 MPa	220	°C	ISO 75
HDT 1,80 MPa	210	°C	ISO 75
CTI	500	V	IEC 60112
Burning Behav. at thickness h	HB	class	UL 94
Thickness tested	1,6	mm	UL 94
UL recognition	-		UL 94
Water absorption	4,50	%	ISO 62
Moisture absorption	1,40	%	ISO 62

TER Plastics
POLYMER GROUP



PROCESSING DATA SHEET

Processing guidelines for injection molding of TEREZ PA 6 7500 GF 50

The processing data sheet provides guidelines about processing as well as pre-drying.

MATERIAL PREPARATION

Storage

Store in a dry place protected from direct sunlight. Avoid all sources of ignition like extreme heat, sparks, or open flame.

Drying

For the manufacturing of mechanically and optically optimal injection molding parts, we recommend following pre-drying conditions according to the table below. If the container is open (wet granules), the drying time can be extended accordingly.

Dry air dryer

Temperature	80°C
Time	4 - 8 hours
Due point	-40°C

Residual moisture

<= 0.05% (recommended)
max. 0.1% (standard)

MACHINE REQUIREMENTS

PROCESSING

Basic settings

The following basic settings are generally to be selected:

Processing temperatures

Hopper	60 - 80°C
Center	240 - 260°C
Nozzle	250 - 270°C

Mold temperature

Temp.	40 - 80°C
-------	-----------

Temperatures

Residence time

You should try to keep the residence time short, especially at high temperatures to avoid material degradation.

Residence times in the cylinder

max. 265 °C / 10 min.

Instructions for cleaning

The aggregate can be cleaned by using low MFI polypropylene. You can also use standard cleaning granulate.