

# Technical information

## TEREZ<sup>®</sup> PA 6.6 7500 MF 40 H

---

Medium viscosity PA66, 40 % mineral reinforced, heat stabilized.



## TECHNICAL DATA SHEET

### Product text

For all kind of molded parts with high stiffness.

Properties	Value	Unit	Test method
Density	1,4900	g/cm <sup>3</sup>	ISO 1183
Impact strength Charpy (Notched 23°C), dry	6	kJ/m <sup>2</sup>	ISO 179
Impact strength Charpy 23°C, dry	100	kJ/m <sup>2</sup>	ISO 179
Tensile-modulus, dry	6000	MPa	ISO 527
Tensile stress at break, dry	80	MPa	ISO 527
Elongation at break, dry	5,00	%	ISO 527
HDT 0,45 MPa	220	°C	ISO 75
HDT 1,80 MPa	147	°C	ISO 75
CTI	550	V	IEC 60112
Burning Behav. at thickness h	HB	class	UL 94
Thickness tested	1,6	mm	UL 94
UL recognition	-		UL 94
Water absorption	5,30	%	ISO 62
Moisture absorption	1,40	%	ISO 62

## PROCESSING DATA SHEET

### Processing guidelines for injection molding of TEREZ PA 6.6 7500 MF 40 H

The processing data sheet provides guidelines about processing as well as pre-drying.

#### MATERIAL PREPARATION

##### Storage

Store in a dry place protected from direct sunlight. Avoid all sources of ignition like extreme heat, sparks, or open flame.

##### Drying

For the manufacturing of mechanically and optically optimal injection molding parts, we recommend following pre-drying conditions according to the table below. If the container is open (wet granules), the drying time can be extended accordingly.

##### Dry air dryer

Temperature	80°C
Time	4 - 8 hours
Due point	-40°C

##### Residual moisture

<= 0.05% (recommended)  
max. 0.1% (standard)

## MACHINE REQUIREMENTS

### PROCESSING

#### Basic settings

The following basic settings are generally to be selected:

##### Processing temperatures

Hopper	60 - 80°C
Center	260 - 290°C
Nozzle	270 - 300°C

##### Mold temperature

Temp.	40 - 80°C
-------	-----------

#### Temperatures

#### Residence time

You should try to keep the residence time short, especially at high temperatures to avoid material degradation.

##### Residence times in the cylinder

max. 280 °C / 8 min.

#### Instructions for cleaning

The aggregate can be cleaned by using low MFI polypropylene. You can also use standard cleaning granulate.